# Lecture-43 **Synchronous Generator**

Lecture delivered by:



### **Topics**

- Synchronous Generator Introduction
- Construction Details of Synchronous Generator
- Principle of operation of Synchronous Generator
- Expressions for Speed and Induced Voltage
- Equivalent Circuit of Synchronous Generator




### **Objectives**

At the end of this lecture, student will be able to:

- Discuss the constructional details of Synchronous Generator
- Describe the principle of operation of Synchronous Generator
- Derive the expressions for Speed and Induced Voltage
- Develop the Equivalent Circuit of Synchronous Generator






View of a two-pole round rotor generator and exciter



#### Introduction

- Unlike the induction machines, rotating air gap field and the rotor rotate at the same speed, called the synchronous speed.
- Synchronous machines are used primarily as generators of electrical power, called synchronous generators or alternators.
- synchronous generators are usually large machines generating electrical power at hydro, nuclear, or thermal power stations.
- Application as a motor: pumps in generating stations, electric clocks, timers, and so forth where constant speed is desired.






# Applications of Synchronous Machines





#### Round Rotor Machine

- •The stator is a ring shaped laminated iron-core with slots.
- Three phase windings are placed in the slots.
- Round solid iron rotor with slots.
- •A single winding is placed in the slots. Dc current is supplied through slip rings.





## Actual View of Round Rotor Machine









#### Salient Rotor Machine

- •The stator has a laminated iron-core with slots and three phase windings placed in the slots.
- •The rotor has salient poles excited by dc current.
- •DC current is supplied to the rotor through slip-rings and brushes.






#### Construction Details of Synchronous Generator





# Actual View of Salient Rotor Machine








- In Synchronous Generator, a DC current is applied to rotor winding (produce rotor magnetic field).
- The rotor is turned by prime mover producing a rotating magnetic field.
- The rotating magnetic field produce three phase sets of voltages within the stator.
- It has:
  - Armature winding [in stator]
  - Field winding [in rotor]



#### **Principle of Operation**

- 1) From an external source, the field winding is supplied with a DC current -> excitation.
- 2) The rotating magnetic field produced by the field current induces voltages in the outer stator (armature) winding. The frequency of these voltages is in synchronism with the rotor speed.





#### Principle of Operation

The rotor of the generator is driven by a prime-mover



A dc current is flowing in the rotor winding which produces a rotating magnetic field within the machine



The rotating magnetic field induces a three-phase voltage in the stator winding of the generator




#### Generated Voltage of Synchronous Generator

The generated voltage of a synchronous generator is given by

$$E = K_c \phi f_e$$

where  $\phi$  = flux in the machine (function of  $I_f$ )  $f_e$  = electrical frequency

 $K_c$ = synchronous machine constant





Saturation characteristic of a synchronous generator.

#### Speed of Rotation of Synchronous Generator

 Synchronous means that the electrical frequency produced is locked with the mechanical rate of rotation of the generator.

$$f_e = \frac{P}{2} f_m = \frac{P}{2} \left( \frac{n_m}{60} \right) = \frac{P n_m}{120} \Longrightarrow$$

$$n_m = \frac{120 f_e}{P}$$

#### Example:

- Determine the rotation speed (r/min)for SG consists of :
  - 2 poles, 50 HZ, 2 poles 60 Hz,
  - 4 poles 50 HZ, 4 poles 60 Hz
- Determine number of poles for 50 Hz operation of SG at 1000 r/min?



#### Induced voltage of Synchronous Generator

Induced voltage in SG is given by following formula

$$E_A = \sqrt{2\pi N_c} \phi f = 4.444 N_c BAf$$

$$E_A = \frac{2\pi f}{\sqrt{2}} N_c \phi = \frac{N_c}{\sqrt{2}} \omega \phi$$

$$E_A = K\phi\omega$$

N = number of turns,

**B**= flux density,

A = cross sectional area of the magnetic circuit,

**f** = frequency,

**φ**= flux per pole

K: constant represents construction of machine

coradian /s


Ea: is proportional to flux and speed, flux depend on the current flowing the rotor field circuits field



# Per Phase Equivalent Circuit of the Synchronous Generator

$$egin{aligned} V_{\phi} &= E_A + E_{stator} \ E_{stator} &= -jXI_A \ V_{\phi} &= E_A - jXI_A \end{aligned}$$

 X: represents the effect of armature reaction reactance only.



$$X_{S} = X + X_{A}$$

$$V_{\phi} = E_{A} - jX_{S}I_{A} - R_{A}I_{A}$$




# Three Phase Equivalent Circuit of the Synchronous Generator

□ The three phases can be either Y or ∆. If they are Y connected, then the terminal voltage VT is related to the phase voltage by

$$V_T = \sqrt{3} V_{\phi}$$

If  $\Delta$  connected:

$$V_T = V_\phi$$



Equivalent circuit of a three-phase synchronous generator



### Summary

- Synchronous generators are usually large machines generating electrical power at hydro, nuclear, or thermal power stations.
- Generated voltage of a synchronous generator is  $m{E} = m{K_c} \ m{\phi} \ f_e$
- In Synchronous Generator, a DC current is applied to rotor winding to produce rotor magnetic field.

