Lecture-62 PMMC

Lecture delivered by:



Topics

- Damping systems required for the Indicating Instruments
- construction and working of PMMC instrument



Objectives

At the end of this lecture, student will be able to:

- Describe the damping systems required for the Indicating Instruments
- Discuss the construction and working of PMMC instrument
- State advantages and disadvantages of Moving coil instruments
- Discuss the applications of MC instruments



Classification of Damping Torque


Air friction damping

Fluid friction damping

Eddy current damping




Air Friction Damping



 Air is used as the medium to suppress the oscillations in an instrument as shown in the figure.



Air Friction Damping





Precautions


• The piston should not touch the walls of the chamber.

Applications

- Hot wire instruments
- Moving iron instruments
- Dynamometer type instruments



Fluid Friction Damping



Fluid (high viscosity damping oil) is used as the medium to suppress the oscillations in an instrument as shown in the figure.



Fluid Friction Damping

- The vanes or discs are attached to the spindle of the moving system.
- It dips into the pot of damping oil .
- The friction of the damping oil opposes the motion of the moving system.
- The damping force increases with the increase in velocity of vane and viscosity of the oil.

Example: Kelvin electro-static voltmeter




Fluid Friction Damping

Disadvantages:

- Oil creeps out if the sealing is not perfect.
- The instrument should be in vertical position.



Eddy Current Damping



Eddy current is used as the medium to suppress the oscillations in an instrument as shown in the figure.



Eddy Current Damping

When the disc rotates in the magnetic field:

- Disc cuts the magnetic lines.
- Eddy currents are produced in the disc.
- Damping force opposes the very cause of producing it (Lenz's law).



Construction of PMMC instruments


Contains:

- U-shaped permanent magnet.
- Light rectangular coil wound on aluminum former used as iron core
- Iron core makes the field uniform and decreases the reluctance of the air path between the poles
- Rectangular coil is supported by jeweled bearings
- Pointer and control springs are attached to the spindle
- Aluminum former provides support to the coil and provides eddy current damping.




Permanent magnet

- Magnet is made of mumetal or alnico.
- Low hysteresis loss.
- Permanent magnet bend like horse shoe magnet






Construction, Working of PMMC





Open view of PMMC instrument





Working of PMMC Instrument

When the disc rotates in the magnetic field:

- Disc cuts the magnetic lines.
- Eddy currents are produced in the disc.
- Damping force opposes the very cause of producing it (Lenz's law).



Advantages of Moving coil instruments

- Consumes less power
- Scale is uniform
- High torque / weight ratio
- Range can be extended
- No hysteresis loss
- Effective and efficient damping
- Not effected by the stray fields



Disadvantages of M.C. instrument

- Delicate construction
- Needs accurate design and assembly of parts
- Errors occurs due to ageing of springs
- Magnets weakens due to ageing



Applications of MC Instruments

- 1. Laboratories on control panel to measure voltage and current etc.
- 2. Workshops to know the value of voltage, current power etc.
- 3. Sub-stations and power stations.
- 4. Irrigation pumps
- 5. Automobiles etc.



Summary of Damping Systems

Air friction damping :

The pressure inside the air chamber opposes the motion of the piston (deflecting torque).

Fluid friction damping:

The friction of the damping oil opposes the motion of the moving system.

Eddy current damping :

The eddy currents produced in the disc causes damping torque



Summary of PMMC

- It works on the D.C motor Principle.
- When a current carrying conductor placed in a magnetic field, it starts moving.
- Controlling torque is produced by the phosphor bronze springs.
- Damping torque is produced by eddy current induced in the aluminum former.

